G-MODS-XBOX-360-USER-GUIDE

USAGE INSTRUCTIONS

10 Mode **:G-MODS-XBOX-360**

This Mod has 10 Modes.

To change modes Press the Tactile Switch.

(Wait until LED stops flashing before pressing Tact Switch again.)

MODES

1.RT RAPIDFIRE ADJUSTABLE

2.RT/LT RAPIDFIRE ADJUSTABLE

3.3 ROUND BURST ADJUSTABLE

4.LT QUICK SCOPE ADJUSTABLE

5.DROPSHOT RAPIDFIRE ADJUSTABLE

6.SNIPER BREATH

7.AUTO RUN

8.AIMKNEEL

9.DROPSHOT RESET NO RAPIDFIRE

10.LT AUTO AIM NO RAPIDFIRE

GENERAL USAGE INSTRUCTIONS

Power On: : Press and Release Tact Switch. The Mod LED will flash the number of times

corresponding to the Mode Number it is in.

Change Mode : Press and Release the Tact Switch. The Mod LED will flash the number of times

corresponding to the Mode Number it is in.

Reverse Change Mode : PULL and HOLD the Left Trigger and Press and Release the Tact Switch. The Mod LED will flash the number of times corresponding to the Mode Number it is in.

SLEEP MODE : Turns Mod Off, will restore to current Mode when turned back on.

-**Sleep Mode On:** Press and HOLD the Tact Switch for approximately 2 seconds. When the player Mod LED turns off, release Tact Switch. It is now in Sleep Mode.

-**Sleep Mode Off:** Press the Tact Switch briefly 1 time. The Mod LED will flash the number of times corresponding to the Mode Number it is in. It is no longer in Sleep Mode.

Manual CalibratioN : If you are having trouble with rapid fire not stopping or you are in a drop mode and your guy wants to keep prone CHECK YOUR BATTERIES! If your batteries are not the problem, then your Mod needs to be recalibrated!

-Power Off Controller

-Remove Power Supply (Battery Pack / Play and Charge Cable [and Battery Pack])

****IMPORTANT:** DO NOT Touch the Triggers after this point until Calibration is complete!

-Hold the Tact Switch

-Connect Power Supply

-Power On Controller

-When LEDs start to light, Calibration is complete, release Tact Switch

ADJUSTABILITY : Some Mods have Built-in User Adjustability

-To adjust your speed press and hold the Tact Switch until the Mod LED goes out.

-When the LED is out, Release the Tact Switch then Press and Hold it again until it blinks 3 times. You are now in Adjustment Mode.

-To adjust “DOWN”, tap the Left Trigger, the Mod LED will blink 1 time slow.

-To adjust “UP”, tap the Right Trigger, the Mod LED will blink fast.

-To leave the adjustment mode tap the Tact Switch one time.

-To Delete User Settings, Perform Manual Calibration and your Mod will be restored to Factory Presets.

DEFINITIONS :

Rapid Fire: Mod Automatically pulls Trigger so Semi-Auto Weapons fire as Automatic

SPS: Shots per Second

Mimic: Fires both Akimbo weapons with Right Trigger pull.

Drop Shot: Drops player to Prone when Trigger is pulled

Drop Shot, Reset: Drop to Prone when Trigger Pulled, then Reset to Standing when Released

Aim Kneel: When Left Trigger is pulled player Aims and Crouches, when released player stands.

Auto Aim Down Sight: When Right Trigger is pulled, player Automatically Aims

Auto Run: Player always running when Left Stick is fully forward. (Also, when using Scoped Weapons, player Automatically Holds Breath while aiming)

Tea Bag: Rapidly alternate between crouching and standing

Juuju Hop: Alternate between Crouching and Standing while Firing. (Makes you difficult to target)

Jump Shot: Player will Jump when Trigger is Pulled

Jump/Drop Shop: When Trigger is pulled, Player Jumps then goes Prone

Jump/Drop Shot, Reset: When Trigger is pulled, Player Jumps the goes Prone. Resets to Standing when Trigger is Released

Left Trigger Drop Shot: Player Aims and goes Prone when Left Trigger is Pulled

Left Trigger Drop Shot, Reset: Player Aims and goes Prone when Left Trigger is Pulled. Resets to Standing when Trigger is Released

Quick Scope: Aim, Fire, Reload Sniper Rifles with single Trigger Pull

Sniper Double-Tap: Fires most Semi Auto Weapons in 2 Round Bursts

Zombies/Campaign Lock: Jiggles Aim so weapons lock on target faster in Zombie Mode. (Also, in

Multiplayer with Assault Rifles and SMGs, it Jiggles Aim slightly to increase your hit probability)

NOTES**: :**

-When Changing Modes etc... the Mod will not function until flashing is complete.

-You must wait until LED is finished flashing before pressing Tact Switch again, or the mode will not change.

-Always keep your batteries as fresh as possible.

-If your Mod is malfunctioning, change the batteries. If that does not fix the problem, perform the Manual Calibration.

-For Quick Scope, Equip the Sleight of Hand Perk when Creating your Class in MW3.

-When using Rapid Fire with Assault Rifles such as the MK14, the Rapid Fire Attachment greatly increases fire rate.